



hp LaserJet
4100mfp • 4101mfp



i n v e n t

**service
addendum**



hp LaserJet 4100mfp series

service addendum _____

Copyright Information

© 2002 Hewlett-Packard
Company

All Rights Reserved.
Reproduction, adaptation, or
translation without prior written
permission is prohibited, except
as allowed under the copyright
laws.

Publication number
C9148-90909

Second edition, April 2002

**Quick reference
service PIN code:
04410002**

Warranty

The information contained in this
document is subject to change
without notice.

Hewlett-Packard makes no
warranty of any kind with respect
to this information.

HEWLETT-PACKARD
SPECIFICALLY DISCLAIMS
THE IMPLIED WARRANTY OF
MERCHANTABILITY AND
FITNESS FOR A PARTICULAR
PURPOSE.

Hewlett-Packard shall not be
liable for any direct, indirect,
incidental, consequential, or
other damage alleged in
connection with the furnishing or
use of this information.

Trademark Credits

Adobe[®], Acrobat[®], PostScript[™],
and the Acrobat logo are either
registered trademarks or
trademarks of Adobe Systems
Incorporated in the United States
and/or other countries/regions.

Microsoft[®], MS-DOS, and
Windows[®] are U.S. registered
trademarks of Microsoft Corp.

Netscape[™] is a U.S. trademark
of Netscape Communications
Corporation.

TrueType[™] is a U.S. trademark
of Apple Computer, Inc.

ENERGY STAR[®] is a U.S.
registered service mark of the
United States Environmental
Protection Agency.



Table of contents

List of figures

List of tables

1 Product Information

Introduction	14
Product configurations	14
HP LaserJet 4100mfp (C9148A)	14
HP LaserJet 4101mfp (C9149A)	14
Product features	15
Product speed and throughput	15
Image quality	15
Paper handling	15
Copying capability	15
Expandable design	16
Product specifications	16
Media specifications	18
Special considerations for ADF documents	18
Supported media for the glass	18
Model and serial numbers	19
Product overview	20
Front view	20
Back view	21

2 Service approach

Service approach	24
Major assemblies	24
Contact HP	25
World Wide Web	25
HP support assistant CD-ROM	25
HP authorized resellers and support	25
HP service agreements	25

3 Operation

Using the ADF unit	28
General guidelines for using the ADF unit	28
Using the glass	29
General guidelines for using the glass	29
Using the control panel	30

Layout and operation	30
Navigation	31
Walk-up copy display	31
Status bar	31
Menus	32
Configure device, diagnostic, and service menus	32
Menu map	33

4 Maintenance

Cleaning the product	36
General guidelines	36
Running the cleaning page	37
Cleaning the ADF delivery guide (clear mylar strip)	37
User-replaceable parts	39
Replacing user-replaceable parts	39
Updating product firmware	41
Downloading a remote firmware update	41
Installing the update	41
RFU installation messages	41
Using HP Web JetAdmin (single update)	42
Using HP Web JetAdmin (multiple or unattended update)	42
Windows parallel connection (local printer)	43
Windows parallel connection (network printer)	43
Troubleshooting RFU installation	44
RFU installation error messages	44
Performing hard-drive disk initialization	45
Cold Reset	45
NVRAM initialization	46
Calibration	47
Performing automatic Calibration	47
Performing manual calibration	48
Lead adjustment for the ADF	48
Center adjustment for the ADF	49
Leading-edge adjustment for the glass	49
Side-edge adjustment for the glass	50

5 Theory of operation

Introduction	52
Overview	52
Document transportation process	52
Document exposure system	52
Light-conversion process	53
General descriptions	54
Scan-unit components	55
ADF components	56
Copy processor board	57
CPB terminology	57
Typical scanning-process flow	58
Copy processor board LEDs	59
Scanner controller board	61
ADF motor circuit	61
Optical-unit motor circuit	61
Scan-unit intake-fan motor circuit	61

Scanner controller board connectors	62
Intermediate PCB.	63
Power supply	63
Overcurrent and overvoltage protection	63
Power-supply block diagram.	64
Optical unit	65
Inverter PCB	66
Scanning lamp	66
CCD driver PCB.	66
ADF document-feed system	67
Overview.	67
ADF cover sensor (PS10)	68
Document-detect sensor (PS2)	68
Leading-edge sensor (PS1)	68
ADF motor	68
Document pickup process	68
Document jams	68
Scan-unit intake fan	68

6 Removal and replacement

Removal and replacement strategy.	70
Required tools	70
Before performing service	70
After performing service.	70
Common fasteners.	71
Parts removal order	72
User-replaceable parts	73
ADF input tray	73
ADF pickup roller	74
ADF separation roller	76
ADF separation pad	77
ADF unit	78
Assemblies and covers	79
Control-panel door	79
Scan-unit right-side cover	82
Copy processor board	83
Scan-unit left-side cover	84
Intake fan filter	86
Formatter cage.	87
Scan unit	89
Printing-unit top cover	91
Glass	92
Scanning lamp	93
Optical unit.	95
ADF door open sensor (PS10)	98
Optical-unit drive gear/motor assembly	99
Scan-unit power supply	101
Inverter PCB	103
Scanner controller PCB	104
Intake fan	106

7 Troubleshooting

Troubleshooting process	111
Preliminary operating checks	112
Installation conditions	112
Media condition	112
Unit condition	112
Basic troubleshooting process flow	113
Basic troubleshooting	114
Power-on defects	116
Troubleshooting with the control panel	117
Control-panel display	117
Event log	117
Print the event log	117
Interpret the event log	118
Display the event log	119
Control-panel messages	120
Troubleshooting with the copy processor board	124
User-level and service-level diagnostics	126
ADF paper-path test	126
To print a paper-path test	126
Diagnostic tests	126
To perform a diagnostic test	126
Service-level diagnostics	127
Service menu	127
To access the service menu (PIN code: 04410002)	127
Jam troubleshooting	128
Jams	128
Clearing repeated ADF jams	129
Creating a customer print job	129
Evaluate the information pages	130
Configuration page	130
Configuration-page elements	130
JetDirect page	132
JetDirect-page elements	132
Supplies status page	133
Supplies-page elements	133
Usage page	134
File directory page	135
File-directory-page elements	135
Image-formation troubleshooting	136
Checking the print cartridge	137
EconoMode	137
Image-defect tables	138
Media troubleshooting	140
Isolate a paper path	140
Use the straightest paper path	140
Isolate the source of the jam	140
Determine where media jams occur	140
Is the MFP is misfeeding or creating multifeed jams	140
Isolate a media brand	141
Isolate a media type	141
Wiring diagrams	142

8 Parts and diagrams

Ordering parts, supplies and getting support	144
Parts	144
Related documentation and software	144
Support	144
Accessories	145
Consumables	145
Common hardware	146
HP Laserjet 4100 differences.	146
How to use the parts lists and diagrams	147
Parts lists and diagrams	148
Alphabetical parts list	162
Numerical parts list	164

Index