


HP LaserJet 5200/5200L Series printers

Service Manual



HP LaserJet 5200 Series printers

Service Manual



Copyright and license

© 2006 Copyright Hewlett-Packard Development Company, L.P.

Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

The information contained herein is subject to change without notice.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Edition 1, 3/2006

Part number Q7543-90934

Trademark credits

Microsoft®, Windows®, and Windows NT® are U.S. registered trademarks of Microsoft Corporation.

Linux is a U.S. registered trademark of Linus Torvalds.

PostScript® is a trademarks of Adobe Systems Incorporated.

UNIX® is a registered trademark of The Open Group.

Energy Star® and the Energy Star® logo are U.S. registered marks of the United States Environmental Protection Agency.



Table of contents

1 Product information

Quick access to printer information	2
Printers at a glance	3
HP LaserJet 5200 Series printers	3
Features at a glance	4
Walkaround	6
Control-panel overview	8
Printer software	10
Printer drivers	10
Driver Autoconfiguration	10
Update Now	11
HP Driver Preconfiguration	11
Additional drivers	11
Opening the printer drivers	12
Software for Macintosh computers	12
Installing Macintosh printing system software for networks	13
Installing Macintosh printing system software for direct connections (USB)	13
To remove software from Macintosh operating systems	14
Software for networks	14
HP Web Jetadmin	14
UNIX	14
Linux	15
Utilities	15
HP Easy Printer Care Software	15
Embedded Web server	15
Other components and utilities	15
Selecting print media	16
Supported media sizes	16
Supported media types	18

2 Installation and configuration

What is in the box	20
Identification	21
Model and serial numbers	21
Site requirements	22
Physical specifications	22
Space requirements	22
Input/Output (I/O) configuration	23

Parallel configuration	23
USB configuration	23
Connecting the USB cable	23
Network configuration	24
Manually configuring TCP/IP parameters from the control panel	24
Setting an IP address	24
Setting the subnet mask	25
Setting the default gateway	25
Disabling network protocols (optional)	26
To enable or disable IPX/SPX	26
To enable or disable AppleTalk	26
To disable DLC/LLC	27
Enhanced I/O (EIO) configuration	27
HP Jetdirect EIO print servers	27
Connecting to a network or a computer	27
Installing printer memory	30
To install printer memory	30
Checking DIMM installation	34
Installing CompactFlash cards	35
Checking CompactFlash installation	39
Enabling memory (Windows only)	40

3 Maintenance

Managing supplies	42
Approximate print-cartridge replacement intervals	42
Managing the print cartridge	42
Print-cartridge life expectancy	42
Print-cartridge storage	42
HP print cartridges	42
HP policy on non-HP print cartridges	42
Print-cartridge authentication	43
HP fraud hotline and Web site	43
Checking supply levels	43
To check supplies by using the control panel	43
To check supplies by using HP Web Jetadmin	43
To check supplies using the embedded Web server	43
Replacing supplies and parts	44
Supply replacement guidelines	44
Life expectancy of consumable parts	44
Changing the print cartridge	44
To change the print cartridge	45
Cleaning the printer	48
Cleaning the printer manually	49
Cleaning the paper path using the printer control panel	49
Cleaning spilled toner	50
Vacuum specifications	50

4 Theory of operation

Engine control system	52
Power-on sequence	53

Motors, fans, and solenoids	53
Laser/scanner system	55
Pickup-and-feed-system	56
Cassette (tray 2) pickup mechanism	57
Multipurpose-tray (tray 1) pickup mechanism	58
Jam detection	58
Image-formation system	59
Image-formation process	60
Latent-image formation block	60
Step 1: primary charging	60
Step 2: laser-beam exposure	61
Development block	61
Step 3: developing	61
Transfer block	61
Step 4: image transfer	61
Step 5: separation from the drum	62
Fixing block	62
Step 6: fusing	62
Drum-cleaning block	62
Step 7: drum cleaning	62
Print cartridge	63
Print-cartridge activation	63

5 Removal and replacement

Removal and replacement strategy	66
Introduction	66
Required tools	66
Types of screws	67
Service approach	67
Before performing service	68
After performing service	68
Parts removal order	68
Customer self-repair parts	70
Tray 1 pickup roller	70
Tray 2 pickup roller	72
Tray 2 separation pad	73
Tray 3 retard roller	74
Tray 3 pickup and feed rollers	75
Formatter	76
CompactFlash cards	77
DIMMs	80
Control-panel overlay	84
Duplexer	84
External doors, covers, and panels	86
Right cover	86
Lower back cover	86
Face-up bin	87
Top cover	89
Left cover	92
Left front cover	94

Face-down cover	95
Tray 2	96
Right front cover	96
Right lower cover	97
DC controller cover	100
Cartridge door unit	100
Control panel	108
Internal assemblies	110
Laser/scanner	110
Formatter	111
Fuser	112
Cassette-paper pickup unit	113
Face-down delivery unit	118
Main motor	120
Fuser motor	125
Main fan	126
Sub fan	129
Registration unit	134
Transfer roller	135
Paper-feed unit	136
Printed circuit assemblies (PCAs)	139
DC controller	139
High-voltage power supply	142
Low-voltage power supply PCA	151
Duplexer	155
Duplexer	155
Duplexer left cover	156
Duplexer right cover	157
Duplexer top cover	158
Duplexer back cover	159
Duplexer feed motor	161
Duplexer fan	164
Duplexer PCA	167
500-sheet feeder	169
500-sheet feeder front cover	169
500-sheet feeder left front cover	170
500-sheet feeder left cover	170
500-sheet feeder right front cover	172
500-sheet feeder right cover	173
500-sheet feeder rear dust cover	175
500-sheet feeder paper-pickup unit	176
500-sheet feeder lifter drive unit	180
500-sheet feeder drive unit	182
500-sheet feeder drive PCA	186
500-sheet feeder pickup motor	186

6 Troubleshooting

Introduction	191
Basic troubleshooting checklist	192
Factors that affect printer performance	192

Troubleshooting flowchart	193
Step 1: Does READY appear on the control-panel display?	193
Step 2: Can you print a configuration page?	193
Step 3: Can you print from a program?	194
Step 4: Does the job print as expected?	195
Step 5: Does the printer select the trays?	196
Solving general printing problems	198
Control-panel message types	201
Control-panel messages	202
Replacement-parts configuration	220
Formatter and DC controller	220
Formatter (new)	220
DC controller (new or previously installed in another printer)	220
Formatter	220
Guidelines for using paper	221
Printing special pages	222
Data collection	223
General paper-path troubleshooting	224
Paper-path checklist	224
Jams in tray 1	225
Jams in tray 2 or the optional 500-sheet feeder	225
Common causes of jams	226
Jam locations	227
Jam recovery	229
Clearing jams	230
Clearing jams from the input-tray areas	230
Clearing jams from the print-cartridge area	231
Clearing jams from the output-bin areas	233
Clearing jams from the optional duplexer	235
Solving repeated jams	236
Troubleshooting print-quality problems	238
Print-quality problems associated with media	238
Print-quality problems associated with the environment	238
Print-quality problems associated with jams	238
Image-defect examples	238
Light print (partial page)	240
Light print (entire page)	240
Specks	241
Dropouts	241
Lines	242
Gray background	242
Toner smear	243
Loose toner	243
Repeating defects	244
Repeating image	244
Misformed characters	244
Page skew	245
Curl or wave	245
Wrinkles or creases	246
Vertical white lines	246

Tire tracks	247
White spots on black	247
Scattered lines	247
Blurred print	248
Random image repetition	248
Interface troubleshooting	250
Communication checks	250
AUTOEXEC.BAT standard configurations	250
Parallel MS-DOS commands	250
Printer Job Language (PJL) commands	250
@PJL [Enter]	250
UEL	251
@PJL COMMENT	251
@PJL INFO CONFIG	251
@PJL INFO ID	251
@PJL INFO USTATUS	251
@PJL INFO PAGECOUNT	251
@PJL JOB	251
@PJL EOJ	252
@PJL ECHO	252
@PJL USTATUS JOB=ON/OFF	252
@PJL USTATUSOFF	252
Changing printer-control-panel configuration settings	253
Changing control-panel settings	253
To change a control-panel setting	253
Show address	253
Tray-behavior options	254
Sleep Delay	255
Personality	256
Clearable warnings	256
Auto continue	257
Cartridge low	257
Cartridge-out response	257
Jam recovery	258
RAM disk	258
Language	259
Fuser modes	259
Using the control-panel menus	261
To use the menus	261
Show Me How menu	262
Retrieve Job menu	263
Information menu	264
Paper Handling menu	265
Configure Device menu	266
Printing submenu	266
Print Quality submenu	268
System Setup submenu	271
I/O submenu	275
Resets submenu	276
Diagnostics menu	277

Service menu	278
Tools for troubleshooting	279
Using the configuration page	279
Using the embedded Web server	280
Accessing the embedded Web server	281
Information tab	281
Settings tab	281
Setting the real-time clock	282
Networking tabs	282
Other links	282
Configuration pages	283
Configuration page	283
HP embedded Jetdirect page	283
Paper-handling configuration page	284
Finding important information on the configuration page	284
Print the supplies status page	285
Print the usage page	286
Print the file directory page	288
Print the PCL font list page	289
Print the PS font list page	290
Diagnostics	291
Embedded HP Jetdirect LEDs	291
Heartbeat LED	292
Printer resets	293
Cold reset	293
To perform a cold reset	293
NVRAM initialization	293
To initialize NVRAM	294
Perform the self test	294
Save + Restore	294
Replacing the formatter and the DC controller	295
Replacing the formatter only	295
Replacing the DC controller only	296
Service menu (service PIN codes)	296
Service ID	297
Restoring the Service ID	297
Converting the Service ID to an actual date	297
Test pages	298
Engine-test page	298
Formatter-test page	298
Troubleshooting network printing problems	299
Troubleshooting common Windows problems	300
Troubleshooting common Macintosh problems	301
Troubleshooting Linux problems	303
Troubleshooting common PostScript problems	304
General problems	304

7 Parts and diagrams

Parts	310
How to use the parts lists and diagrams	311

Types of screws	311
Related documentation and software	312
Accessories and supplies	312
External panels and covers	316
Internal components	320
Paper-feed assembly	326
Face-up delivery assembly	328
Face-down delivery assembly	330
PCAs	332
Fuser	334
Cassette (tray 2)	336
Cassette (tray 2) paper-pickup assembly	338
500-sheet feeder cassette (tray 3)	340
500-sheet feeder, cassette, external panels and covers	342
500-sheet feeder internal components	344
500-sheet feeder paper-pickup assembly	346
500-sheet feeder drive assembly	348
500-sheet feeder lifter-drive assembly	350
500-sheet feeder PCA	352
Duplexer	354
Duplexing PCA assembly	358
Duplexing-feed drive assembly	360
Alphabetical parts list	362
Numerical parts list	369

Appendix A Printer specifications

Electrical specifications	378
Power-consumption specifications	379
Acoustic specifications	380
Operating-environment specifications	381

Appendix B Product warranty

Hewlett-Packard Limited Warranty Statement	384
Availability of support and service	385
HP maintenance agreements	386
Next-Day Onsite Service	386

Appendix C Regulatory statements

FCC regulations	388
Declaration of conformity	389
Safety statements	390
Laser safety	390
Canadian DOC regulations	390
EMI statement (Korea)	390
VCCI statement (Japan)	390
Power cord statement (Japan)	390
Laser statement for Finland	391

Index	393
--------------------	------------