



service

hp LaserJet
4200/4250/4300/4350
series printers

HP LaserJet 4200, 4250, 4300 and 4350 Series printers

Service Manual



Copyright and License

© 2004 Copyright Hewlett-Packard Development Company, LP

Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

The information contained in this document is subject to change without notice.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Part number Q5400-90932

Edition 1, 11/2004

Trademark Credits

Adobe®, Acrobat®, and PostScript® are trademarks of Adobe Systems Incorporated.

Corel® is a trademark of Corel Corporation or Corel Corporation Limited.

Energy Star® and the Energy Star logo® are US registered marks of the United States Environmental Protection Agency.

Linux® is a U.S. registered trademark of Linus Torvalds

Microsoft®, Windows®, and Windows NT® are U.S. registered trademarks of Microsoft Corporation.

Unix® is a registered trademark of The Open Group.

Table of contents

1 Product information

Chapter contents.....	1
Printer configurations.....	2
Base model.....	2
n model.....	3
tn model.....	4
dtn model.....	5
dtns model.....	6
dtnsl models.....	7
Model and serial numbers	8
Printer overview.....	9
Hardware components	9
Interface ports.....	11
Software components.....	12
Operating systems and printer components	12
Printer drivers.....	13
Drivers included	13
Additional drivers.....	14
Select the correct printer driver for your needs.....	14
Printer driver Help.....	14
Using the printer drivers.....	15
Software for Macintosh computers	17
PPDs.....	17
HP LaserJet Utility.....	17
Specifications.....	18
Hardware specifications	18
Electrical specifications.....	20
Acoustic emissions.....	22
Print speed specifications	24
Operating environment.....	24
Media specifications.....	25
General guidelines	25
Supported media weights and sizes.....	26
Supported-media specifications tables.....	26
Paper and print media.....	30
Printing and storage environment	30
Supported types of media	31
Guidelines for using paper.....	32
Envelopes.....	34
Envelope construction.....	34

Envelopes with double side-seams.....	35
Envelopes that have adhesive strips or flaps.....	35
Envelope margins.....	35
Envelope storage.....	35
Labels	36
Transparencies.....	36
Card stock and heavy paper	37
Card stock construction	37
Card stock guidelines.....	37
Types of media to avoid.....	38
Hewlett-Packard limited warranty statement.....	39
Print Cartridge Limited Warranty Statement.....	41
Service approach	42
Regulatory information.....	43
FCC regulations.....	43
Environmental product stewardship program.....	44
Protecting the environment.....	44
Ozone production.....	44
Energy consumption.....	44
HP LaserJet printing supplies.....	45
Material safety data sheet.....	46
For more information.....	46
Regulatory statements	47
Country-/region-specific safety statements.....	49
Laser safety statement	49
Canadian DOC statement.....	49
Japanese VCCI statement.....	49
Korean EMI statement.....	49
Finnish laser statement.....	50

2 Installation

Chapter contents.....	51
Operating environment	52
Site requirements.....	53
Software installation.....	54

3 Operation

Chapter contents.....	55
Using the control panel.....	56
Control-panel layout.....	56
Control-panel lights.....	57
Control-panel buttons.....	58
Using the printer Help system.....	58
Settings and defaults	59
Setting the control-panel display language.....	59
Control-panel menus	60
Printing control-panel menus.....	60
To print a control-panel menu map.....	60
To change a control-panel setting.....	61
Retrieve Job menu	62

Information menu.....	63
Paper-handling menu.....	64
Configure-device menu	68
Printing submenu	68
Print-quality submenu	71
System Setup submenu	74
Stapler/stacker submenu	77
I/O submenu	77
Resets submenu (HP LaserJet 4250/4350 only).....	78
Diagnostics menu (HP LaserJet 4250/4350 only)	80

4 Maintenance

Chapter contents.....	81
Cleaning the printer and accessories	82
Cleaning the fuser.....	83
Running the cleaning page manually.....	83
To run the cleaning page manually.....	83
Running the cleaning page automatically.....	85
To run the cleaning page automatically.....	85
Cleaning spilled toner	85
Performing preventive maintenance.....	86
Resetting the maintenance-kit counter (LJ 4200/4300).....	86
Resetting the maintenance-kit counter (LJ 4250/4350).....	87
Maintenance kit part numbers	87
Expected life of components	88
Maintaining the stapler unit.....	89
To remove and replace the stapler unit.....	89
Loading staples.....	90
To load staples	90
Downloading a remote firmware update.....	91
Downloading the new firmware to the printer.....	91
Remote firmware update through a local Windows port	92
Windows 95, Windows 98, or Windows Me	92
Windows NT 4.0, Windows 2000, Windows XP, or Windows Server 2003.....	93
Remote firmware update through a Windows network.....	93
Remote firmware update for UNIX systems.....	93
Remote firmware update using FTP on a direct network connection	93
Windows operating systems	94
Mac operating systems.....	95
Remote firmware update using FTP through a browser.....	96
Remote firmware update using Fetch (Mac OS 8.6 and OS 9.x only)	97
Remote firmware update using the HP LaserJet utility (Mac OS 8.6 and OS 9.x only).....	98
Remote firmware update using the LPR command	99
Using HP Web JetAdmin to download the firmware to the printer.....	100
Printer messages during firmware update.....	101
Troubleshooting a firmware update.....	102

5 Theory of operation

Chapter contents.....	103
Introduction	104

Basic operation of the printer.....	105
Printer operating sequence.....	105
Control system overview.....	105
Pickup-and-feed system overview.....	106
Laser/scanner system overview.....	106
Image-formation system overview.....	106
General descriptions	107
Dc controller PCA.....	108
Motor and fan control.....	109
Power supply.....	110
Fuser-control circuit.....	110
Fuser over-temperature protection	111
Overcurrent/overvoltage protection.....	111
Laser/scanner assembly.....	112
Paper-pickup-and-feed system.....	114
Pickup-and-feed block	116
Printing from tray 1	117
Printing from tray 2	119
Tray 2, 500-sheet feeder, and 1,500-sheet feeder media-size detection.....	119
Lifter-driver operation.....	120
Multiple-feed prevention.....	121
Media-skew prevention.....	121
Fuser/delivery block.....	122
Jam detection.....	122
Printer pickup delay jam from tray 1.....	123
Printer pickup delay jam from tray 2.....	123
Printer pickup stationary jam.....	123
Printer-delivery wrap jam when feeding regular media.....	123
Printer delivery wrap-jam when feeding irregular media.....	123
Printer delivery-delay jams.....	124
Printer door-open jam	124
Printer residual-media jam.....	124
Printing from the 500-sheet feeder.....	125
500-sheet feeder pickup and feeding.....	126
Printing from the 1,500-sheet feeder.....	128
1,500-sheet feeder pickup and feeding.....	129
1,500-sheet feeder lifting mechanism.....	131
Envelope feeder.....	132
Envelope-feeder pickup and feeding.....	132
Envelope feeder jam detection	133
Envelope feeder pickup delay jam.....	133
Envelope feeder pickup stationary jam.....	133
Duplexer.....	134
Reversing and duplexer pickup.....	135
Duplexer jam detection	136
Stacker and stapler/stacker	137
Stacker.....	139
Stacker feed and delivery.....	139
Stacker jam detection.....	141
Stacker-feed jam	141

Stacker-feed stationary jam.....	141
Stacker residual-media jam.....	141
Stapler/stacker	142
Stapler/stacker feed and delivery.....	142
Staple-mode feed and delivery.....	144
Stapler unit.....	148
Stapler-unit operation	149
Staple level-detection.....	151
Stack-mode feed and delivery.....	151
Stapler/stacker jam detection	152
Stapler/stacker feed jam	152
Stapler/stacker feed stationary jam.....	152
Stapler/stacker delivery jam.....	152
Stapler/stacker residual media jam.....	152
Image-formation system	153
Electrostatic latent-image formation.....	155
Primary charging	155
Writing the image	155
Developing the image	156
Transferring the image	157
Fusing the image	158
Cleaning the transfer charging roller and photosensitive drum.....	159
Print-cartridge memory chip.....	160
Formatter system.....	161
PowerSave (LJ 4200/4200L/4300) or Sleep (LJ 4250/4350) Mode.....	161
Resolution Enhancement technology	162
EconoMode	162
Input/output.....	162
Parallel interface.....	162
USB (HP LaserJet 4250/4350 Series printers only).....	162
Embedded ethernet print server (HP LaserJet 4250/4350 Series printers only).....	162
Expanded I/O.....	163
Flash (HP LaserJet 4200/4300 Series printers only).....	163
CompactFlash card (HP LaserJet 4250/4350 Series printers only).....	163
Hard-disk accessory.....	163
CPU	163
Printer memory	163
Read-only memory	163
Random-access memory	163
DIMM slots	164
Firmware DIMM (LJ 4200/4200L/4300 only).....	164
Nonvolatile memory.....	164
Memory Enhancement technology	164
PJL overview	164
PML.....	165
Control panel	165

6 Removing and replacing parts

Chapter contents.....	167
-----------------------	-----

Removal and replacement strategy.....	168
Required tools.....	168
Before performing service	169
After completing service	169
Screws used in the printer	170
Parts-removal tree	171
Printer input tray, and cabinet wheel locks.....	172
Dc controller PCA diagram.....	173
User-replaceable parts	175
Print cartridge	175
Transfer roller	177
Fuser.....	178
Tray 1 pickup roller	179
Tray 1 separation pad.....	181
Tray 2 feed rollers.....	182
Covers, tray 1, and the rear output bin.....	186
Accessory covers and the tray 2 extension door	187
Formatter cover.....	191
Top cover.....	192
Right-side cover	195
Left-side cover.....	197
Front cover.....	198
Tray 1.....	200
Rear output bin.....	203
Control-panel display.....	204
Control-panel overlay	204
Control-panel assembly	205
Main assemblies	209
Firmware DIMM (LJ 4200/4300 only).....	210
Formatter assembly	211
Reinstallation notes, formatter	212
Installing a new formatter and a new dc controller (LJ 4250/4350 only).....	213
Output-delivery assembly	214
Duplexing-pendulum assembly.....	217
Laser/scanner assembly.....	219
Paper-pickup drive assembly	222
Tray 2 lifter-drive assembly.....	227
Dc controller PCA.....	230
Reinstallation tip.....	235
Installing a new formatter and a new dc controller (LJ 4250/4350 only).....	235
Power supply.....	236
Paper-feed belt assembly.....	243
Motors and fans.....	245
Main cooling fan (left side)	246
Cooling fan, right side (HP LaserJet 4250/4300/4350 Series printers only)	248
Removing the fan without removing the air duct.....	248
Removing the fan and the air duct together.....	251
Print-cartridge motor (HP LaserJet 4250/4300/4350 series printer only).....	253
Main motor	255
Pickup and feed assemblies	257

Tray 1 paper-pickup assembly	257
Paper-feed assembly.....	261
Reinstallation notes for the paper-feed assembly.....	262
Main drive assembly.....	263
Registration assembly.....	266
Sensors and switches.....	268
Tray 2/500-sheet feeder media-size sensor (PS101).....	269
Tray 2 media-size sensor (PS101)	269
500-sheet feeder media-size sensor.....	270
Tray 1 paper sensor (PS105).....	272
Door switch (SW101).....	273
Solenoids and clutches.....	274
Tray 2 pickup solenoid (SL101).....	275
Tray 1 pickup solenoid (SL102).....	276
Feed-roller clutch (CL101).....	277
Accessories	278
500-sheet feeder assembly.....	278
500-sheet feed rollers.....	278
500-sheet feeder right-side cover.....	278
500-sheet feeder control PCA	281
500-sheet feeder lifter-drive assembly	282
500-sheet feeder paper-pickup drive assembly.....	283
1,500-sheet feeder assembly.....	288
1,500-sheet feeder feed rollers.....	288
1,500-sheet feeder separation roller	288
1,500-sheet feeder door.....	290
1,500-sheet feeder rear cover.....	291
1,500-sheet feeder right-side cover	292
1,500-sheet feeder control PCA	294
1,500-sheet feeder media-size sensor.....	296
1,500-sheet feeder lifter-drive assembly	297
1,500-sheet feeder paper-pickup drive assembly.....	300

7 Troubleshooting

Chapter contents.....	301
Introduction	302
Troubleshooting process.....	303
Initial troubleshooting checklist.....	303
Troubleshooting flowchart	305
Power-on checks.....	306
Overview.....	306
Troubleshooting tools	309
Information pages.....	310
Menu map.....	311
Configuration page	312
Supplies status page	314
Embedded Web server	315
Gaining access to the embedded Web server.....	315
Information tab	315
Settings tab	316

Networking tab	316
Other links	317
Printer Status and Alerts software	317
To select status messages.....	318
To view status messages and information.....	318
Control-panel menus	319
Using control-panel menus.....	319
Resets submenu	320
Diagnostics menu	321
Service menu (service PIN codes).....	323
Service ID	324
Converting the Service ID to an actual date.....	324
Restoring the Service ID	324
Printer resets and power-on modes.....	325
Cold reset	325
To perform a cold reset	325
NVRAM initialization	326
To initialize NVRAM	326
Hard-disk initialization	327
To initialize the hard disk.....	327
Power-on bypass.....	328
Skip disk-load	328
Self-test.....	328
Test pages	329
Engine-test page	329
Formatter test page	330
Interface troubleshooting	331
Communications checks.....	331
Computer direct connect (parallel) test	331
EIO troubleshooting	331
Jetdirect page/Embedded Jetdirect page (HP LaserJet 4250/4350 Series printers).....	332
Display-message troubleshooting	333
Status messages	333
Warning messages	333
Error messages	333
Critical-error messages	333
Alphabetical printer messages	333
Alphabetical printer messages.....	334
Numerical printer messages	348
Numerical printer messages.....	348
Paper-path troubleshooting.....	365
Overview.....	365
Jam recovery	366
To disable the jam recovery.....	366
Avoiding jams	367
Persistent jams	368
Basic troubleshooting for persistent jams.....	368
Data collection	368
General paper-path troubleshooting.....	368

Paper-path checklist.....	369
Paper-path test	369
To perform a paper-path test.....	370
Jams in tray 1	371
Jams in tray 2	372
Jams in tray 3 or tray 4.....	373
Jams in the paper path	374
Jams in the duplex path	374
Media transport problems	375
Multiple pages feed	375
Media is wrinkled or folded.....	375
Media is skewed	376
Image-formation troubleshooting	377
Media-related print-quality problems	377
Overhead transparency defects	378
Print-quality problems that are related to the environment.....	378
Print-quality problems that are related to jams.....	378
Image defects	379
Image quality	379
Check the print cartridge.....	380
EconoMode.....	380
Half self-test functional check	381
Drum-rotation functional check.....	381
Image defect tables.....	382
Repetitive-defects troubleshooting	400
Troubleshooting the stacker and the stapler/stacker.....	402
Initial checks	402
Jam errors	403
Stacker and stapler/stacker paper path.....	403
Stacker paper-path test.....	404
Stapler/stacker paper-path test.....	404
Paper-transport errors.....	406
Malfunction errors.....	406
Component errors.....	407
Printer-component locations.....	409
Main printer parts.....	409
Printer switches and sensors.....	413
Printer motors and fans.....	414
Printer PCAs.....	415
Accessory component locations.....	416
500-sheet feeder main parts.....	416
500-sheet feeder switches, sensors, solenoids, and PCAs.....	417
1,500-sheet feeder main parts.....	418
1,500-sheet feeder switches, sensors, solenoids, and PCAs.....	420
Stapler/stacker stapler assembly.....	421
Stacker and stapler/stacker switches and sensors.....	422
Stacker and stapler/stacker motors and solenoids.....	423
Stacker and stapler/stacker PCAs.....	424
Printer and accessory wiring diagrams.....	425
HP LaserJet 4200 wiring diagram	426

HP LaserJet 4250 wiring diagram	427
HP LaserJet 4300 wiring diagram	428
HP LaserJet 4350 wiring diagram	429
500-sheet feeder wiring diagram.....	430
1,500-sheet feeder wiring diagram.....	431
Duplex accessory wiring diagram.....	432
Envelope-feeder-accessory wiring diagram.....	433
Stacker-accessory wiring diagram.....	434
Stapler/stacker-accessory wiring diagram.....	435
Dc controller connectors diagram.....	436
General timing diagrams.....	437
HP LaserJet 4200 general timing diagram.....	438
HP LaserJet 4250 general timing diagram.....	439
HP LaserJet 4300 general timing diagram.....	440
HP LaserJet 4350 general timing diagram.....	441
Stapler/stacker timing diagram.....	442

8 Parts and diagrams

Chapter contents.....	443
Ordering parts and supplies.....	444
Parts.....	444
Related documentation and software.....	444
HP-authorized resellers and support.....	445
HP service agreements.....	445
HP Partner Portal.....	445
Supplies.....	446
Consumables and accessories.....	447
Consumables.....	447
Accessories.....	448
Memory, fonts, and mass storage	450
Cables and connectivity.....	452
Formatters, laser/scanners, power supplies, and fusers.....	453
Assembly locations (1 of 3)	454
Assembly locations (2 of 3)	455
Assembly locations (3 of 3)	456
Covers.....	458
Internal components.....	462
Accessories.....	484
Alphabetical parts list.....	494
Numerical parts list.....	503

Index.....	513
------------	-----